How to Fix a Glitchy Chromebook Screen (Step-by-Step Guide)

TechRounder PDF Edition

Live article: https://www.techrounder.com/how-to/fix-glitchy-chromebook-screen/

By Vipin PG | Published November 20, 2026 | Updated November 20, 2026 | Format: Guide | 12 min read

Quick answer

To fix a glitchy Chromebook screen, first work out whether the problem is in software or in hardware. Software glitches usually clear with a restart, an update or a settings change.

To fix a glitchy Chromebook screen, first work out whether the problem is in software or in hardware. Software glitches usually clear with a restart, an update or a settings change. A loose display cable or a failing panel will not respond to any reset.

"Glitchy" can mean flickering, lines, colored bars, static or an image that shifts and melts, and each of these points to a different cause. This guide shows you how to tell them apart with two quick tests, then walks through the fixes in order, from a simple restart to a full reset. It also tells you when to stop and ask for a repair or a warranty claim.

The short version:

- Flicker or drifting brightness is usually software, power or backlight. Start with a restart, an update and a hard reset.
- Lines or glitches that change when you move the lid almost always mean a loose or damaged display cable. Resets will not fix this.
- Static, colored blocks or a "melting" image point to the panel, the graphics chip or the motherboard. The external monitor test below shows which.
- A glitch in one app or site only is a narrow software issue. Update that app or turn off graphics acceleration.

First, identify what kind of glitch you have

The symptom is your best clue, so match what you see to this table before you change any settings.

What you see: Whole screen flickers or pulses, brightness drifts | Most likely cause: Software, power or backlight | Can you fix it at home?: Often yes, with no parts needed

What you see: Lines or bars that appear or worsen when you move the lid | Most likely cause: Display cable at the hinge | Can you fix it at home?: Rarely, because it is a hardware repair

What you see: Static, colored blocks, corrupted areas, a "melting" image | Most likely cause: Panel, graphics chip or motherboard | Can you fix it at home?: Sometimes, if the external monitor test points to software

What you see: Black screen with white lines | Most likely cause: Panel or display cable | Can you fix it at home?: Usually no

What you see: Glitch in one app, one site or video playback only | Most likely cause: Graphics acceleration, an extension or the app itself | Can you fix it at home?: Yes

What you see: Flicker only while charging | Most likely cause: Charger or power delivery | Can you fix it at home?: Often yes, with the original charger

No one has published reliable figures on how often glitches come from software and how often from hardware, so use the table to decide where to look first. It is not a diagnosis.

Quick fixes to try first

These four steps cost nothing and change no settings. Test the screen after each one.

1. Clean the screen with a dry microfiber cloth. Press the brightness keys to check that the screen is not simply dimmed, and make sure Night Light is off. A warm tint or a dim panel is often mistaken for a fault.

2. Do a full restart. Shut the Chromebook down, unplug the charger, wait 10 seconds, then power it on. Closing the lid does not count. A restart clears temporary graphics glitches.

3. Update ChromeOS. Go to Settings > About ChromeOS > Check for updates, install anything waiting, then restart. Display bugs are sometimes fixed in a later update.

4. Try a hard reset. On most Chromebooks with a keyboard, turn the device off, hold the Refresh key (F3), tap Power, and release Refresh when the Chromebook starts. This resets the keyboard, touchpad and other built-in hardware. It does not touch your account.

Check your model before step 4. Tablets, detachables and some older Chromebooks use a pinhole reset button, a Power and Volume Up hold, or unplugging the power instead. Google lists the method for each device. Google also warns that a hard reset might delete some files in your Downloads folder, so copy anything important to Google Drive first.

If you have an older Chromebook, open Settings > About ChromeOS > Additional details to see its automatic update expiry date. A device that no longer gets updates cannot benefit from step 3, and a fault that survives everything else here may be a good reason to replace it.

If the screen still glitches, run the two tests below. They decide which of the remaining fixes are worth your time.

The two-minute test that shows if it is hardware

These tests split the problem into software and hardware, which saves you from trying fixes that cannot work.

Test 1: the lid test

Open and close the lid slowly while you watch the screen. Do not twist the lid or press on the panel.

- If the glitch changes with the lid angle (lines appear, or the flicker starts or stops), the display cable in the hinge is the likely cause. That is a hardware fault, and no reset will fix it.
- If the glitch ignores the lid angle, go on to Test 2.

Test 2: the external monitor test

Connect the Chromebook to a TV or monitor with HDMI or USB-C, and look at both screens.

What you see: The external screen shows the same glitch | What it means: The picture is corrupted before it reaches the panel. The cause is ChromeOS, graphics or firmware, or occasionally the motherboard | Where to go next: Software fixes, then the last-resort resets

What you see: The external screen is clean and the built-in screen glitches | What it means: The built-in panel or its cable is at fault | Where to go next: The hardware section and warranty

What you see: Both screens are clean most of the time but glitch with certain apps or sites | What it means: A narrow software issue | Where to go next: Software fixes

If the glitch changes with the lid, treat it as a cable fault whatever the monitor shows. If it survives every software fix below, skip the factory reset, because a reset cannot repair a cable or a panel.

Software fixes, in order

Try these if the glitch also shows on the external monitor, appears only in some apps, or does not change with the lid. Some may be locked on a school or work Chromebook (see the managed devices section below). Test the screen after each step.

1. Reset Chrome flags. Type ‘chrome://flags‘ in the address bar, select Reset all, then Restart. Experimental graphics flags left switched on can cause flicker. Reset them instead of trying new ones.

2. Turn off graphics acceleration. Open ‘chrome://settings/system‘ , switch off "Use graphics acceleration when available" if you see it, then relaunch. This helps when flicker or tearing happens inside the browser. Not every ChromeOS version shows the option, so skip this step if it is missing.

3. Adjust display settings. Go to Settings > Device > Displays and try a different display size or resolution. Toggle "Use built-in scaling" if it is shown, and change the refresh rate if your model offers one. Turn Night Light off for a while, because color-temperature shifts and scaling can look like banding or flicker.

4. Test in a fresh profile. Add another user or use Guest mode and check the screen there. If the glitch disappears, a profile or extension is the cause. Go back to your own account and disable extensions one at a time.

5. Check the charger. If the flicker appears or gets worse while charging, try the original charger and cable, since a cheap or failing USB-C charger can make the screen unstable. Unplug any dock, USB-C hub or HDMI adapter too, then test again.

6. Isolate a single app. If only one app or website glitches, update that app, clear its cache, or load the same site in a different browser window. Video calls and Android apps often tear for reasons that have nothing to do with the screen.

On many newer Chromebooks you can also open the Diagnostics app from Settings > About ChromeOS, or by searching "Diagnostics" in the launcher. What it includes varies by ChromeOS version and model, so do not rely on it to rule out a display fault.

If the glitch started after an update and looks like a software bug, press Alt + Shift + I to send feedback to Google with a screenshot. It will not fix your screen, but it helps get the problem addressed.

If it is a hardware fault

Glitches that change with the lid, or that appear only on the built-in screen, point to hardware. The cause is usually one of two things.

- A thin cable carries the picture from the motherboard through the hinge to the panel. When that cable or its connector works loose or wears out, you see flicker, lines or bars that come and go as you move the lid. Repair threads from technicians often trace this kind of fault to the display connector.

- A failing panel or backlight causes constant lines, static bars, colored blocks, shifting image areas or brightness that wanders on its own, whatever the lid position. Manufacturers treat persistent lines as a panel fault.

A smaller group of cases comes from a loose memory module, corrupted firmware or a motherboard fault. These usually come with other symptoms, such as the Chromebook failing to boot or shutting down at random.

What you can safely check

1. Look closely at the screen and frame for cracks, pressure marks or liquid residue. Damage like this means a repair, not a settings change.

2. Think about when the glitch started. A drop, a bag squeezing the lid or a spill is useful information for a repair shop.

3. Feel whether the hinge is loose, stiff or gritty.

Before you open the case

Most Chromebook screens are sealed and are not meant to be replaced by the user. Opening the case to reseat the display cable or the memory can void your warranty, and on a school or work device it can break your organization’s rules. Do it only on an out-of-warranty device you own, and only if you are comfortable with small connectors. Repair guides such as iFixit’s cover the procedure for specific models.

Reseating the display cable has mixed results. People who tried it report success, but the reports are anecdotal, and the fix often does not last if the cable itself is worn.

Last-resort resets: Powerwash and Recovery

Use these only if the glitch also showed on the external monitor and the software fixes above did not help. If the glitch changes with the lid or appears only on the built-in screen, skip this section. A reset cannot repair a cable or a panel, and you would lose your local data for nothing.

Back up first. Both options erase everything stored on the Chromebook, including your Downloads folder. Copy important files to Google Drive or an external drive, and let Drive finish syncing before you start. Files already in Google Drive are not deleted.

Option 1: Powerwash (factory reset)

1. Sign out of your Chromebook.
2. At the sign-in screen, press and hold Ctrl + Alt + Shift + R.
3. Select Restart.
4. In the box that appears, select Powerwash, then Continue.
5. Sign in with your Google account and set the device up again.

If the glitch is gone, a corrupted profile or system state was the cause. If it comes back after a Powerwash, the cause is most likely hardware.

Option 2: ChromeOS Recovery

Recovery removes ChromeOS and reinstalls it. Use it when a Powerwash did not help and you still suspect the operating system.

1. On another computer, use the Chromebook Recovery Utility extension in Chrome to create a recovery USB drive. The tool erases the drive, and a drive of 8 GB or more is the usual requirement.
2. On the glitching Chromebook, enter recovery mode. On many models you hold Esc + Refresh and press Power. Some models have a recovery button instead.
3. Insert the USB drive, or choose "Recover using internet connection" if your device offers it, and follow the on-screen steps.

If recovery fails, try a different USB drive, since some drives do not work well with it. If you are unsure how to enter recovery mode on your model, check the manufacturer’s support page before you start.

When to stop and claim warranty or repair

Stop troubleshooting when the glitch changes with the lid, shows only on the built-in screen, or comes back after a Powerwash. More resets will not help at that point. The next step is a warranty claim or a repair quote.

Your situation: Within the warranty period | What to do: Contact the manufacturer or seller. Do not open the case yourself, because that can void the warranty

Your situation: School or work device | What to do: Report it to your IT admin, who may replace the device

Your situation: Out of warranty, newer or higher-priced model | What to do: Get a written repair quote for the cable or panel

Your situation: Out of warranty, old or entry-level model | What to do: Compare the repair quote with the price of a replacement

Your situation: Past its automatic update date | What to do: Replacing it is often the better use of money, since the device will not get new fixes

A common rule of thumb is to replace a Chromebook when the repair quote comes close to half the price of a comparable new one. Panel and cable costs vary a lot by model and region, so get a quote before you decide.

What to tell support or a repair shop

- The exact symptom: flicker, lines, bars, static, or a black screen with lines.
- Whether it changes when you move the lid.
- Whether the glitch also showed on an external monitor.
- What you already tried, such as a restart, a hard reset or a Powerwash.
- When it started, and whether there was a drop, a spill or pressure on the lid.

The lid test and the monitor result help a technician most, because they show whether the fault is the cable, the panel or something else.

School or work Chromebooks, and brand notes

Managed devices

If your Chromebook belongs to a school or employer, your administrator controls many settings. Google states that you cannot factory reset a managed Chromebook yourself, and some display settings may be locked too. Try the quick fixes and the lid and monitor tests, which need no admin rights. Then report the glitch to your IT team with your notes instead of repeating resets that will not work.

Brand notes

The steps in this guide apply to every Chromebook. These notes point to manufacturer help for common brands.

Brand: HP | Worth knowing: Documents a hard reset by holding Power and Refresh for about 10 seconds. The HP Community has flicker reports on specific models, such as the 14a series

Brand: ASUS | Worth knowing: Publishes a built-in screen troubleshooting FAQ that follows the same order: clean, restart, update, reset, then service

Brand: Dell | Worth knowing: Has a Chromebook screen troubleshooting article that sends persistent panel faults to service

Brand: Lenovo | Worth knowing: Community reports of lines on the screen concentrate on certain models, such as the C330

Look up your exact model number on the manufacturer’s support pages, because the hard reset method and warranty terms differ by model.

How to stop it happening again

You cannot prevent every hardware fault, but a few habits lower the risk of both kinds.

- Install ChromeOS updates when they appear, and restart the Chromebook weekly.
- Leave experimental flags alone. If you tried some, reset them at ‘chrome://flags‘ .
- Use the original charger, or a reputable replacement made for your model.
- Open the lid from the center instead of one corner, so the frame does not flex.
- Do not stack weight on a closed Chromebook, and use a padded sleeve in a bag.
- Avoid pressing on the screen when you clean it, and check that no cable or pen is caught when you close the lid.
- Back up to Google Drive regularly, so a reset or repair never costs you files.

Frequently asked questions

Why is my Chromebook screen flickering?

The usual causes are a software or settings problem, an unstable charger, or a loose display cable. Flicker that changes with the lid angle points to the cable. Flicker on both the built-in and an external screen points to software, graphics or firmware. The lid test and the external monitor test show which one you have.

Can a Chromebook screen glitch be fixed without repair?

Often yes, if the cause is software. A restart, an update, resetting Chrome flags, changing display settings or using the original charger fixes many cases. If the glitch changes with the lid or appears only on the built-in screen, it is a hardware fault and needs a repair.

Does Powerwash fix screen flickering?

Only when the cause is a corrupted profile or system state. It cannot repair a loose display cable or a failing panel. If the glitch also shows on an external monitor, a Powerwash is a reasonable last software step. Back up your files first, because it erases local data.

How do I know if my Chromebook screen is broken or it is a software problem?

Connect an external monitor. If the external screen is clean and the built-in one glitches, the panel or its cable is at fault. If both glitch, look at software, graphics or firmware. A glitch that changes as you move the lid is almost always the display cable.

Why does my Chromebook screen glitch when I move the lid?

A thin display cable runs through the hinge to the panel. Moving the lid flexes it, and if the cable or its connector is loose or worn, the picture breaks up. Software resets cannot fix this, so it needs a repair or a warranty claim.

Is a glitchy Chromebook screen covered under warranty?

That depends on the manufacturer’s terms and the cause. Many warranties cover a defective panel or cable but not physical damage such as cracks or spills. Check your purchase date and coverage, and do not open the case yourself, since that can void the warranty.

Sources

- Reset your Chromebook hardware , Google Chromebook Help
- Reset your Chromebook to factory settings , Google Chromebook Help
- Recover your Chromebook , Google Chromebook Help

- Reset (Powerwash) your Chromebook to factory settings , ASUS Support

References

1. support.google.com - chromebook / answer - https://support.google.com/chromebook/answer/3227606
2. support.google.com - chromebook / answer - https://support.google.com/chromebook/answer/183084
3. support.google.com - chromebook / answer - https://support.google.com/chromebook/answer/1080595
4. asus.com - us / support - https://www.asus.com/us/support/faq/1042702/